



You will simply have to connect the 10pin wire coming off the LED (Red Circle) and the 5 pin wire coming off the louver motor (Green Circle) into the circuit board. You can leave the grey 5 pin wire and the other ones loose, since they are optional (wired thermostat).

